

AW4416 DIAGNOSTICS

Rest In Peace: MSG (DijonStock.com)

Turn the power on then use the following key combinations:

UTIL + HOME = full assembly diagnostics

UTIL + [1-16] = MAIN sheet diagnostics

UTIL + [17-24 RTN] = PN diagnostics

UTIL + MON = SUB sheet diagnostics

HOME + MON = Format a new hard drive/reset boot-up